

Kit12

For further information visit:
support.lampspares.co.uk
And search for IS04 in the search box.

Ref:
IS-04

Kit Contains:

1x Cable Cord Set	1x Cord Grip
1x BC Lampholder	1x Nut cover
1x All Thread Rod	2x Steel Nuts
1x Plastic Washer	1x Tube Cover
2x Steel washers	
1x Tube Grommet	

Before you start please ensure you are competent to carry out electrical works and ensure the electricity is turned off.

If in any doubt stop what you're doing and seek professional advice.

Step 1: Take the All threaded rod and add a nut followed by a Steel washer and then the plastic washer.

Step 2: Pass this assembly up from inside the vase and out the top. Adding a steel washer followed by a nut, tighten up to secure the assembly to your light base.

Leaving enough thread sticking out the top for the tube cover to slide over, Leaving an approx. 6mm of thread sticking out the top.

- For the 38mm kit leave 50mm of thread sticking out the top of the lamp base.
- For the 75mm Kit leave 87mm of thread sticking out the top of the lamp base.

Step 3: Add the nut cover over the top of the nut and thread followed by the all thread tube cover.

Step 4: Take the lampholder and separate it into its 3 parts, the base, the connection unit and the skirt.

Step 5: Screw the lampholder's base section on top of the 6mm thread sticking out the top of the cover.

Step 6: Push the tube grommet into the bottom of the all thread rod then pass the cable cord set through the hole in the side of your fitting then install the cord grip before pushing the cable into the all threaded rod.

Step 7: Take the connection unit of the lampholder and connect the unit please turn over for the connection instruction's. Finally screw the lampholder's skirt on top to finish off the installation.

Wiring of the lampholder



If you have any concerns or difficulties in connecting this product please contact us on details at the bottom of this manual.

All electrical parts confirm to BS 60238 and have full CE approval.

Certification can be obtained on request via email.

Please Note: This picture is for reference, It does not matter which way around the Live and Neutral goes.

The Lamp Holder has to be assembled back correctly for the light bulb to work. If the light bulb does not work please ensure the following process has been checked.


Please see images below for correct alignment of the BC Lampholder.



Top View



Indent Alignment



**LIAQA
ASSURED
COMPANY**



Unit 3 Brookside Business Park | Brookside Avenue | Rustington | West Sussex | BN16 3LP

© Lampspares. All Rights Reserved E:contact@lampspares.co.uk | T:01903 776644